





V13




## 1. Install

Install UltraLoq product and download "U-tec" app to smartphone.




## 2. Plug In

Plug Bridge into a power outlet within 10 ft (3 m) from UltraLoq. Yellow LED will be steady.



## 3. Connect


Use U-tec app to pair the UltraLoq device. On the Lock Setting screen in the App, connect to the Bridge and follow the instructions. Yellow LED will blink.



## 4. Use

Unlock your UltraLoq and check its status from anywhere with an internet connection.

**ULTRALOQ**



**ULTRALOQ**



## Light Status

### Green

(1) Steady - Sleeping mode

### Yellow

(1) Steady - Smart-config (Factory Reset) state  
(2) Blinking - System boot / Configuration in progress

### Blue

(1) Steady - Data transfer with Ultraloq

### Red

(1) Steady - Cannot connect to Wi-Fi  
(2) Blinking - Cannot connect to Ultraloq via Bluetooth

## FAQ

### 1) If two or more Bridges were plugged in, how to identify them when connecting?

To connect to designated Bridge, please only keep the designated Bridge plugged and unplug other Bridges.

### 2) What to do if red LED appears?

- Make sure if the Wifi is 2.4GHz.
- Restart the router and check Wifi connecting well.
- Unplug and re-plug Bridge.

### 3) What to do if blue LED appears?

- Bridge and lock should be near each other within 10ft / 3m.
- Press the Restart button on the lock.
- Close and re-open the App.
- Unplug and re-plug Bridge.

## Ultraloq Terms & Policies

Before using all Ultraloq products, please read all applicable terms, rules, policies and usage provisions found at [www.u-tec.com/company/privacy](http://www.u-tec.com/company/privacy). By using your Ultraloq, you agree to be bound by the U-tec Privacy Policy.